

Fastboy, Regular and Large Fender Bag

Please read completely before installation!

Installation Instructions

Tools: 2 large tip flat bladed screwdrivers, drill, 1/4" bit, soldering iron or sharp knife, Loctite Blue

Time: 10 minutes

- 1) Open the fender bag and remove the plastic sheet.
- 2) Pick a location on your fender.
- 3) Mark the plastic sheet with proper locations for mounting holes, a minimum of about 3/4" from the edge of the plastic. **Drill 1/4" holes. Use a correctly sized drill!**
- 4) Using the plastic sheet as a template, mark locations on your fender and **drill 1/4" holes.**
- 5) Using the plastic sheet as a template, mark locations in the fender bag. Melt holes with a soldering iron or similar, or cut holes with a sharp knife and seal the nylon edge with a match.
- 6) Insert the plastic sheet into the fender bag.
- 7) Bolt your bag on. From top to bottom, the proper order of the fasteners is:
barrel nut – washer – plastic sheet - fender bag – bike fender - washer – screw

I recommend **use of a small amount of thread locker** such as Loctite Blue or a similar product. *Check the fit of the barrel nuts, washers and screws before applying the thread locker.*

Care of your fender bag

- When you get the fender bag very muddy, take a second and use your finger to wipe the mud off the zipper before opening. This will help to keep the zipper from derailing.
- You can certainly use a power washer on your bag if you like.
- No other care needed.

Fastboy, Regular and Large Fender Bag

Please read completely before installation!

Installation Instructions

Tools: 2 large tip flat bladed screwdrivers, drill, 1/4" bit, soldering iron or sharp knife, Loctite Blue

Time: 10 minutes

- 1) Open the fender bag and remove the plastic sheet.
- 2) Pick a location on your fender.
- 3) Mark the plastic sheet with proper locations for mounting holes, a minimum of about 3/4" from the edge of the plastic. **Drill 1/4" holes. Use a correctly sized drill!**
- 4) Using the plastic sheet as a template, mark locations on your fender and **drill 1/4" holes.**
- 5) Using the plastic sheet as a template, mark locations in the fender bag. Melt holes with a soldering iron or similar, or cut holes with a sharp knife and seal the nylon edge with a match.
- 6) Insert the plastic sheet into the fender bag.
- 7) Bolt your bag on. From top to bottom, the proper order of the fasteners is:
barrel nut – washer – plastic sheet - fender bag – bike fender - washer – screw

I recommend **use of a small amount of thread locker** such as Loctite Blue or a similar product. *Check the fit of the barrel nuts, washers and screws before applying the thread locker.*

Care of your fender bag

- When you get the fender bag very muddy, take a second and use your finger to wipe the mud off the zipper before opening. This will help to keep the zipper from derailing.
- You can certainly use a power washer on your bag if you like.
- No other care needed.